



# **DEHUMIDIFIER**

## **LDHU-A10**

# DEHUMIDIFIER LDHU-A10

Dehumidifier LDHU-A10 is electrical refrigeration humidifier unit with powerful moisture removal capacity of 24 L/ day. It works by drawing moist air over a refrigerated evaporator with a fan. Features digital display humidity monitor which shows current air humidity. It consumes low power energy efficient the auto modes are automatically adjusting the humidity levels.

## FEATURES

- ◆ Effectively removes moisture, dust from the air
- ◆ Humidity levels are automatically adjusted.
- ◆ Designed with system Auto shut-off / auto restart
- ◆ Quiet fan has two speed settings
- ◆ Laundry drying function
- ◆ 24-hour timer to set the time of operation
- ◆ Electronic control Panel
- ◆ Device content antibacterial filters.
- ◆ Performs Continuous drainage or 5 L water tank
- ◆ Auto-Defrost at low temperature

## APPLICATION

Dehumidifier applied across diversified industries like pharmaceutical, food, lithium battery manufacturing, defence, power, chemicals, electronics, leather and many more. They are successfully installed across research and development (R&D), manufacturing, processing, drying, testing, storage and packaging areas in almost all industries.

## SPECIFICATION

ModelNo.	LDHU-A10
Dehumidifying capacity at 30°C and 80% RH)	24 L / 24h (01 day)
Water Tank	5.0 L
Refrigerant	R290
Noise	≤ 43 dB (A)
Input power	280 W
Input current	1.25 A
Loading Quantity	324 / 666/ 888
Supply Voltage	AC 220 V to 240 / 50Hz
Dimension (D×W×H)	310 × 210 × 565 mm
Net Weight	13.5 kg