

Portable Brake Fluid Refractometer

LBFR-A10



Portable Brake Fluid Refractometer LBFR-A10

Portable brake fluid refractometer LBFR-A10 is a microprocessor controlled pocketsized optical instrument that provides instant measurement readings. Digital meter displays easy to read results. Automatic power off post one minute of last operation prolongs it's battery life. Ideal for determining boiling points of DOT3 and DOT4.

Features

- Microprocessor controlled
- LCD screen to display measurement data in one view
- Automatic and zero calibration with distilled or tap water
- Abrasion and corrosion-resistant coating on sapphire prism
- Automatically turns off after 1 minute of non-use

Applications

Used in laboratories, research institutes, chemical industry, automobile industry, etc.

Specifications

Model	LBFR-A10
DOT 3 measuring range	121 °C ~ 260 °C
DOT 4 measuring range	125 °C ~ 275 °C
Refractive index	1.3330 nD ~ 1.5177 nD
Battery	1.5 V
Dimensions	121 × 58 × 25 mm
Weight	90 grams